


1902 McGaw Avenue Irvine CA 92614 949.567.9000 949.567.9010 fax

General Roller Bearing Clearence Guidelines



 \varnothing HOUSING BORE = \varnothing CRANK PIN + (2 × \varnothing ROLLER) + 0.0008" \varnothing HOUSING BORE = \varnothing CRANK PIN + (2 × \varnothing ROLLER) + 0.020 mm